

MODERN HARDWARE For Your Home

Mila Joshu 1987



Is your home modern, really modern? Undoubtedly it is equipped with electric lights, hot and cold water, a furnace, bath and toilet, but how about those few extra touches which give your home the appearance of being up-to-the-minute in every particular? How about those conveniences which add so much to your comfort, and which, should the time ever come when you desire to sell, would make people anxious to buy your home? These few extra touches will increase the value of your home many hundreds of dollars.

It is with these improvements, few in number—but great in effect, that this booklet is concerned.

You will find that a careful study of the following pages can not help but be of value to you.

Richards-Wilcox Mfg. Co.

neanolis

AURORA, ILLINOIS, U.S.A.

Chicago New York Cleveland
Boston St.Louis Indianapolis
RICHARDS-WILCOX CANADIAN CO. LE
Winnipeg LONDON, ONT


Los Angeles San Francisco





Modern Hardware for Your Home

Catalog No. A-33



W. H. FitchPresident and General Manager Lee MighellVice-President Milton D. Jones Secretary and Treasurer P. L. Hoffman Superintendent

BRANCHES

New York City	t
Chicago	t
Philadelphia	t
Boston	Ĺ
Cleveland 459 Hippodrome Annex	
Kansas City 203 Reliance Bldg. Omaha 215 City Natl. Bank Bldg.	•
Omana	•

St. Louis	1735 Boatmens Bank Bldg.
Minneapolis	321 Plymouth Bldg.
Los Angeles	503 Equitable Bldg.
San Francisco	626 Underwood Bldg.
Indianapolis	423-424 Occidental Bldg.
Seattle	1214 Hoge Bldg.
Cincinnati	Provident Bank Bldg.


Canadian Plant

Richards-Wilcox Canadian Co., Ltd.....London, Ont. Branch Offices at Winnipeg and Montreal

MAIN OFFICE AND WORKS:

AURORA, ILLINOIS, U.S. A.









Richards-Wilcox Products

For Homes

Multifold Window Hardware. Vanishing Door Hardware. Swing Door Checks. Stair Rail Brackets. Woodworking Vises, Benches. Kitchen Grindstones. Foot Scrapers.

For Barns

Sliding Door Hardware.
Gable Door Hardware.
Wicket Door Hardware.
Locks, Latches, Bolts.
Hinges and Stay Rollers.
Door Pulls and Handles.
Door Stops and Holders.
Stair Rail Brackets.
Woodworking Vises, Benches.
Mounted Grindstones.
Malleable D Handles.
Fence Stretchers.
Wagon Jacks.

For Private Garages

"Slidetite" Door Hardware.
"SlydaSyde" Door Hardware.
"CornR-Wise" Door Hardware.
"Round-Runner" Door Hardware.
Straight Sliding Door Hardware.
Parallel Door Hardware.
Flush Door Hardware.
Wicket Door Hardware.
Electric Door Operator.
Locks, Latches, Bolts.
Door Pulls and Handles.
Door Stops and Guides.
Door Checks and Holders.
Woodworking Vises, Benches.
Mounted Grindstones.
Heavy Hinges.

For Public Garages

"Slidetite" Door Hardware.
Lift Door Hardware.
Vertical Door Hardware.
Horizontal Door Hardware.
Electric Door Operator.
Automobile Turn Table.
Fire Doors.
Automatic Fire Door Hardware.
"OveR-Way" Conveying Equipment.
See "For Private Garages."

For Schools, Churches

Parallel Door Partition Hardware. Accordion Door Partition Hardware. Flush Door Partition Hardware. Wardrobe House Door Hardware. Warlshing House Door Hardware. Multifold Window Hardware. Swing Door Checks. Stair Rail Brackets. "Ideal" Elevator Door Hangers. "Ideal" Elevator Door Controllers. Electric Theatre Curtain Operator. Fire Doors, Fusible Links.

"Lowe" Automatic Fire Door Release. Automatic Fire Door Hardware. Woodworking Vises and Benches. Grindstones and Grinders. "OveR-Way" Conveying Systems.

For Sanitariums, Hospita's

Parallel, Accordion and Flush Partition
Door Hardware.
Vanishing House Door Hardware.
"Ideal" Elevator Door Hangers.
"Ideal" Elevator Door Controllers.
Automatic Fire Door Hardware.
"Lowe" Automatic Fire Door Release.
Fire Doors, Fusible Links.
Multifold Window Hardware.
Swing Door Checks.
Door Stops and Holders.
Stair Rail Brackets.
Heavy Hinges.

For Business Houses

Sliding Door Hardware.
Wicket Door Hardware.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
"Lowe" Automatic Fire Door Release.
Swing Door Checks, Holders.
Heavy Hinges.
Stair Rail Brackets.
Elevator Door Hardware.
Elevator Door Controllers.
Rolling Store Ladders.
Multifold Window Hardware.
"OveR-Way" Conveying Systems.
Woodworking Vises, Benches.

For Office Buildings

"Ideal" Elevator Door Hangers.
"Ideal" Elevator Door Controllers.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
"Lowe" Automatic Fire Door Release.
Swing Door Checks.
Vanishing House Door Hardware.
Stair Rail Brackets.
Rolling Store Ladders.
Heavy Hinges.
Multifold Window Hardware.
Electric Theatre Curtain Operator.

For Fire Stations

Hardware for Automatic Fire Station Doors.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
Stair Rail Brackets.
Heavy Hinges.
Swing Door Checks.
Door Holders.
Mounted Grindstones.

For Shops

"OveR-Way" Conveying Systems. I-Beam Trolleys. Mounted Grindstones. Woodworking Vises, Benches. Sliding Door Hardware. Lift Door Hardware.
Heavy Hinges.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
Wicket Door Hardware.
Swing Door Checks.
Locks, Latches, Bolts.
Door Pulls, Handles.
Door Stops, Guides, Holders.

For Industrial Plants

Vertical Door Hardware.
Horizontal Door Hardware.
"PieR-Work" Door Hardware.
Lift Door Hardware.
Wicket Door Hardware.
Electric Door Operator.
Swing Door Checks.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
"Lowe" Automatic Fire Door Release.
"OveR-Way" Conveying Systems.
I-Beam Trolleys.
Chain Hoists.
Dumping Buckets.
Mounted Grindstones.
Woodworking Vises, Benches.
Rolling Store Ladders.
Heavy Hinges.
Stair Rail Brackets.
Malleable D Handles.

For Warehouses


Warehouse Door Hardware.
Parallel Door Hardware.
Vertical Door Hardware.
Horizontal Door Hardware.
Folding Door Hardware.
"PieR-Work" Door Hardware.
Lift Door Hardware.
"Monarch" Mill-Type Doors.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
"OveR-Way" Conveying Systems.
I-Beam Trolleys.
Heavy Hinges.
Mounted Grindstones.
Swing Door Checks.
Door Stops, Holders, Locks.
Stair Rail Brackets.

For R. R. Entrances, Round Houses

Round House Door Hardware.
Heavy Hinges.
Warehouse Door Hardware.
Lift Door Hardware.
"Monarch" Mill Type Doors.
Fire Doors, Fusible Links.
Automatic Fire Door Hardware.
"OveR-Way" Conveying Systems.
I-Beam Trolleys.
Swing Door Checks.
Door Stops, Holders, Locks.
Mounted Grindstones.
Malleable D Shovel Handles.


If you have not received one of our No. 30 General Catalogs, one will be gladly sent upon request.













What Users Say About "AiR-Way"

The letter quoted below is typical of many which we have received from satisfied home-owners:

Milton, Penn.

"I mailed to you today, under separate cover, a photograph of my sun room in which I installed the hardware which I purchased from you.

"I want to say to you again that I am certainly well pleased with the hardware. I have had absolutely no trouble in opening the windows and everyone who has seen the lay-out say they have never seen anything like it. We practically lived in the sun room all summer and the combinations we were able to make for ventilation were most unusual.

"Yours very truly,
"W. W. Wilson."

Here Is What Another Owner Says:


"We do not believe that there is anybody in the United States who appreciates AiR-Way multifold window hardware more than our family," says W. E. Frost. "Our house faces east and south, which is the prevailing direction of the storms in this section, and formerly every time there was a thunder shower or storm we had a drenched porch, as the rain would blow three-quarters of the way across it and flood the floor. It was impossible to keep a varnished floor or any kind of furniture in the porch as the weather ruined it.

"Now when it rains we have an enclosed room. And in pleasant weather we have an open porch. During the winter months in the chilly morning we have a room that is easily heated

up with a Perfection Oil Heater.

"We have yet to have the first person come on this porch who has not been struck with the arrangement of the windows. I took an architect out there the other day, who declared that in the future on all of his open work he will use the AiR-Way fixtures."





Wide Open



Hanger for any Door that Slides'





Like Dining Out-of-Doors

The windows of the modern dining room are equipped with AiR-Way Multifold Window Hardware. Thus they may be thrown wide open to the gentle, cooling breezes, affording all the comforts of outdoor dining while retaining the conveniences of the indoor dining room.

On stormy days and in winter, snug-fitting AiR-Way windows exclude all rain, wind and cold. They're absolutely weather-tight and rattle-proof when closed.



Showing how the bedroom with AiR-Way equipped windows may quickly be converted into an airy sleeping porch.

Fresh Air by Night



Kitchen Comfort All the Year

AiR-Way Multifold Window Hardware brings all the comfort of grandmother's outdoor summer kitchen to the modern home.

AiR-Way equipped windows enable you to quickly convert your hot, stuffy kitchen into a pleasant, breezy porch.













Let the Outdoors In

With "AiR-Way" Multifold Windows



Sash Thrown Wide Open


Opened to give the open porch effect. Notice that there are no mullions or other obstructions in the opening. Window screens can be used if desired, as the operation of "AiR-Way" windows in no way interferes with them.



Storm-tight—The sash are tightly sealed against the wind, rain or cold. See illustration on page 11 for tight application









"A Hanger for any Door that Slides"

Interior Views

In each series or group of sash, the sash hinged to the window casing is opened first. The remaining sash of the series slide toward this end sash when it is opened



The second sash has now been opened. The third and fourth sash open in the same manner, as shown by the top illustration on opposite page.



All of the sash of one series may be partly opened so as to have full ventilation and at the same time avoid the direct force of the wind.

Wind and draught will not blow sash from position you leave them in; they will stand immovable in any position, open, partly opened or closed, without locks or holders.















Drapery Suggestions


Lambrequin on Transom, Drapes on Individual Sash

Flowered or Figured "Cut-Out" Lambrequin of Cretonne with "Tie-Back" Curtains of Flowered Marquisette.



Lambrequins and Tie-Back Drapes


Lambrequins of Diana or Terry Cloth. Drapes of Curtain Goods, Grenadine or Pongee.



Scalloped Shades on Transom

Choice of-

Duplex (Two-Tone) Shade Cloth, Holland Linen, all colors, or Hand Opaque Cloth.




Fancy Scalloped Lambrequins

Diana Cloth, Terry Cloth, or Cretonne offer many pleasing patterns.

We do not furnish Lambrequins, Shades or Curtains.








"A Hanger for any Door that Slides

Drapery Suggestions


Shirred Lambrequins with Tie-Back Curtains

Lambrequins of the same color but of a darker shade than the curtains, of colored Madras. Many beautiful combinations are possible.



Individual Scalloped Shades


Astrakhan Cloth is charming—and very satisfactory. Striped Denim is unique.



Scalloped Shades with Gathered Curtains

Shades of Holland Linen, Duplex or Hand Opaque Cloth.


Curtains of Swiss, Grenadine or Shadow Tuscan.



Shirred Curtains for Individual Sash

There are many handsome curtain materials to choose from, but of them all, none is more beautiful than Shadow Fibre Silk.

We do not furnish Lambrequins, Shades or Curtains.







The Simple Construction and Easy Working of "AiR-Way" Multifold Window Equipment





Fig. 1. Exterior view shows where sash links, which connect the series of sash, are applied. The link at the top of each cash applied parallel with and works on the same principle as the nak at the bottom of each sash. Also note the metal track and their looks. safety locks.



THE "AiR-Way" method of operating a series of windows in a row is far in advance of existing older methods.

Instead of hanging each sash independently on hinges which require a number of solid mullions or jambs, this new scheme is to connect several sash in a series (as illustrated on previous pages), so that they can be folded up and leave a clear space much larger than the space obtainable by the old method.

In a living room, for example, a wide opening can be made almost the width of the room, but this large space can be covered in a moment by a series of folding windows, which when not in use, are folded up conveniently at the side of the opening.

How Accomplished

Just a word as to the means by which this is accomplished. First there is a piece of track fitted on to the lintel on the top frame, and a similar piece of track is fitted on to the sill at bottom of frame as shown in Figs. 10 and 11 on opposite page.

The sash are connected together by adjustable sash links (see Fig. 2), which are attached to the sash in the manner shown in Fig. 1. These links connect the sash together both top and bottom. You will notice on the adjustable sash link (Fig. 2) a little wheel. These wheels run in the top track and bottom track previously referred to. That is what keeps the sash in place. The end sash nearest the jamb is fastened to jamb or side frame by hinges and this sash is the first one to be opened. As this sash swings, the link which connects it with the next one in the series pulls the entire string of sash in that direction.

Special Locking Feature

As soon as the first sash is opened, even two or three inches, the second sash may be partly opened in the same way and this in turn releases the lock which holds the third sash and so on. But the sash must be opened in order. The advantage of this arrangement is that when the sash are all closed, locking the end sash locks the entire series against incorrect operation.

(Continued on next page)





Fig. 7. Fig. 8. Chafing Plate. Rubber Ston.











Fig. 2. Adjustable Sash Link.
One of these links connects each sash, at the top and bottom, with the sash adjacent.



Fig. 4. Thumb Fastener.







Fig. 6 Butt Hinge





"A Hanger for any Door that Slides"

This Installation Will Materially Increase the Selling Value of Your Home

A S the several windows are opened they follow each other across the opening until finally all of the sash are lined up compactly in a small space at end of the opening out of the way.

It is to be noted, especially, that each sash will remain in the position to which it is opened without shaking or rattling. You may have one, two or more windows opened without opening the entire series if desired.

Do Not Interfere With Screens

It is an important advantage of this method of hanging windows, that they do not interfere with screens or storm sash. When sash are mounted to fold outside, it is impossible to use screens unless they are mounted *inside*, in which case, it is either necessary to move the screens in order to operate the windows or else to install an expensive operating device in the sill.

Size Sash Should Be

"AiR-Way" hardware is applied to any number of sash the builder may want to place in a row, but we recommend that not more than four sash of maximum width be installed to form a string sliding one way. Five sash may be used if the total width of the series does not exceed 8 feet. Height of the window does not affect the operation of this hardware, but the hardware is designed for sash not more than 12 square feet in area and maximum width of sash not to exceed 24 inches. It is advisable to keep each opening within the limitation of a span 11 feet in width for windows having transom sash when our standard design of transom bar is used, or 16 feet 6 inches for windows having no transom sash and a total vertical sash height of five feet.




Fig. 10. Cross-section through sash and window frame at top showing installation of "AIR-Way" track above sash and tight application of sash.

Mill Work

The operation of windows hung on "AiR-Way" Multifold Hardware is extremely simple, but it is, of course, necessary that the sash and frames should be properly made and the hardware properly put on. It is best that the sash and frames be made by the millman and that the sash be fitted in the frame and the hardware put on at the mill. The work can then be shipped to the job and erected easily into the outer frame. This insures a tight job and one that will operate smoothly.

We supply a full set of blue prints for the millman so that he will know exactly how to make the sash and frames and how to attach the hardware. It is not a difficult job if the instructions are followed.

The Cost

As to the cost of the material, it does not cost much more, if any more, to put up "AiR-Way" windows than to put up the ordinary swing casements, provided they are equipped with the same quality of hardware that we supply on the "AiR-Way" sets.

The finest "AiR-Way" hardware is solid brass. Tracks and storm threshold are solid brass, and will, therefore, not rust or deteriorate.

Other parts of the hardware are made in three finishes; solid brass, brass plated and dead black, but for permanent satisfaction we recommend the set in solid brass.

A List Price of hardware is found on each page where complete sets are shown.

	71.71.07	Finish	Finish	Finish
	List Price of Parts	No. 1	No. 2	No. 3
No. 312.	Bow Handle Fasteners, each	\$2.50	\$2.00	\$1.75
	Thumb Fasteners, each	1.80	1.10	.90
No. 312.	Chafing Plates, each	.40	.30	.20
No. 312.	Rubber Stops, each	.80	.60	.40
No. 312.	Sill Stops, each	.80	.60	.40
No. 312.	Safety Locks, each	1.60	1.20	.80
No. 312.	Sash Links, each	2.50	2.00	1.50
No. 312.	Butt Hinges, per pair	2.60	.60	.60
No. 312.	Storm Thresholds, per foot	.50		
No. 312.	Lower Track, per foot	.80		
No. 312.	Upper Track, per foot	.60		

Finish No. 1—Solid Brass, Safety Locks, dull brass. brass finish. All other parts brushed brass finish. Tracks and Thresholds, natural

Finish No. 2—Safety Locks, solid brass, dull brass finish. Tracks and Thresholds, natural brass finish. All other parts plated brushed brass finish.

Finish No. 3—Tracks and Thresholds, natural brass finish. All other parts dull black, imitation Bauer-Barrf finish.

A set of working Blue Prints giving Construction Data will be furnished upon request.





Fig. 11. Cross-section through sash and window frame at bottom showing installation of "Allt-Way" track below sash and tight application of sash using brass threshold or storm sill. Note arched groove in bottom of sash just back of threshold. This groove obviates the possibility of moisture following the bottom of the sash.









Richards-Wilcox Mfg. Co. Aurora, Illinois

R-W No. 312

"AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 4' 3" Wide by 5' High





Sash Closed



Sash Partly Opened



Sash Wide Open

2-Sash, Folding One Way

Same Hardware Can Be Used on Sash Opening to Right or to Left

We recommend that sash be about 20" wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one Tracks and Thresholds are sent in 4'3" lengths.

Material Furnished

4 Sash Links	1 Safety Lock
2 Butt Hinges	1 Sill Stop
2 Rubber Stops	1 Chafing Plate
2 Fasteners with Bow Handles	1 Pc. Upper Track
1 Pkg. Assorted Screws	1 Pc. Lower Track
1 Set of Erection Details	1 Pc. Threshold


List Price


2-Sash Set.—Hardware complete for opening not over 4'3" wide (between finished frames) x 5' high,

Weight, per set, 11 lbs. Finish No. 1—Solid Brass, per opening......\$22.60

Same hardware can be used on sash opening to right or to left

Discount












''A Hanger for any Door that Slides

R-W No. 312

"AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 6' 3" Wide by 5' High



Same Hardware Can Be Used on Sash Opening to Right or to Left

We recommend that sash be about 20" wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Track and Thresholds are sent in 6'3" lengths.

Material Furnished

- 6 Sash Links
- 2 Butt Hinges
- 4 Rubber Stops
- 3 Fasteners with Bow
 - Handles
- 1 Pkg. Assorted Screws
- 1 Set of Erection Details

- 2 Safety Locks
- 1 Sill Stop
- 2 Chafing Plates
- 1 Pc. Upper Track
- 1 Pc. Lower Track
- 1 Pc. Threshold




3-Sash Set-Hardware complete for opening not over 6'3" wide (between finished frames) x 5' high.

Weight, per set, 16½ lbs.


Finish No.	1.	Solid Brass, per opening\$32.60
Finish No.	2.	Brass Plated, per opening 26.70
Finish No.	3.	Black, per opening



Sash Closed



Sash Partly Opened



Sash are Weather Tight and Rattle Proof When Closed



Sash Wide Open










14

Richards-Wilcox Mfg. Co. Aurora, Illinois


R-W No. 312

"AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 8' 3" Wide by 5' High



One Sash Opened.



Two Sash Opened.



All Sash Partly Opened.

4-Sash, Folding One Way

Same Hardware Can Be Used on Sash Opening to Right or to Left

We recommend that sash be about 20 inches wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in 8 foot 3 inch lengths.

Material Furnished

8	Sash	Lin	S

O Dasii Links

2 Butt Hinges 6 Rubber Stops

4 Fasteners with Bow Handles

1 Pkg. Assorted Screws

1 Set of Erection Details

3 Safety Locks

1 Sill Stop

3 Chafing Plates

1 Pc. Upper Track


I Pc. Lower Track

1 Pc. Threshold

List Price

4-Sash Set—Hardware complete for opening not over 8 feet 3 inches wide (between finished frames) by 5 feet high. Weight, per set, 21% lbs.

Finish No. 1.	Solid Brass, per opening\$	12.60
Finish No. 2.	Brass Plated, per opening	35.40
Finish No. 3.	Black, per opening	31.40









'A Hanger for any Door that Slides'

R-W No. 312 "AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 8' 6" Wide by 5' High



2-Sash Folding Each Way

Two 2-Sash Sets Will Accomplish the Same Results

We recommend that sash be about 20 inches wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in two lengths, each 4 feet 3 inches long.

Material Furnished

- 8 Sash Links
- 4 Butt Hinges
- 4 Rubber Stops
- 4 Fasteners with Bow Handles
- 1 Pkg. Assorted Screws
- 2 Safety Locks


- 2 Sill Stops
- 2 Chafing Plates
- 2 Pcs. Upper Track
- 2 Pcs. Lower Track
- 2 Pcs. Threshold
- Set of Erection Details
- List Price


4-Sash Set (2 folding each way)—Hardware complete for opening not over 8 feet 6 inches wide (between finished frames) by 5 feet high.

Weight, per set, 221/2 lbs.

Finish No. 1.	Solid Brass, per opening\$45.20
Finish No. 2.	Brass Plated, per opening 36.00
Finish No. 3.	Black, per opening 32.00

Discount.....






Sash Closed.




Two Sash Closed-Two Sash Open.



All Sash Wide Open.








Richards-Wilcox Mfg. Co. Aurora, Illinois


R-W No. 312 "AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 8' 3" Wide by 5' High






Sash Closed.



Two Sash Closed-Three Sash Partly Open.



All Sash Wide Open

5-Sash

Folding One Way

Same Hardware Can Be Used on Sash Opening to Right or to Left

We recommend that sash be about 20 inches wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in 8 foot 3 inch lengths.

Material Furnished

10 Sash Links	1 Sill Stop
2 Butt Hinges	4 Chafing Plates
8 Rubber Stops	1 Pc. Upper Track
5 Fasteners with Bow Handles	1 Pc. Lower Track 1 Pc. Threshold
1 Pkg. Assorted Screws	Set of Erection Details


4 Safety Locks

List Price

5-Sash Set—Hardware complete for opening not over 8 feet 3 inches wide (between finished frames) by 5 feet high. Weight, per set, 24 lbs.

Finish 1	No.	1.	Solid Brass, per opening\$51.60
Finish 1	No.	2.	Brass Plated, per opening 43.10
Finish 1	No.	3.	Black, per opening 38.10

Discount.....







Hanger for any Door that Slides"

R-W No. 312

"AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 12' 6" Wide by 5' High

6-Sash

3-Sash Folding Each Way

Two 3-Sash Sets Will Accomplish the Same Results

We recommend that sash be about 20" wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in two lengths, each 6'3" long.

Material Furnished

- 12 Sash Links
- 4 Safety Locks
- 4 Butt Hinges
- 2 Sill Stops
- 8 Rubber Stops
- 4 Chafing Plates
- 6 Fasteners with Bow Handles
- 2 Pcs. Upper Track
- 1 Pkg. Assorted Screws
- 2 Pcs. Lower Track
- 1 Set of Erection Details
- 2 Pcs. Threshold

List Price


6-Sash Set--Hardware complete for opening not over 12'6" wide (between finished frames) x 5' high.

Weight, per set, 33 lbs.


Finish No. 1. Solid Brass, per opening\$65.20

Finish No. 2. Brass Plated, per


opening 53.40 Finish No. 3. Black, per opening... 47.40




Sash Closed



All Sash Partly Open






All Sash Wide Open










18

Richards-Wilcox Mfg. Co. Aurora, Illinois

R-W No. 312 "AiR-Way" Multifold Window Hardware For Opening Not Exceeding 16' 6" Wide by 5' High

8-Sash


4 Sash Folding Each Way Two 4-Sash Sets Will Accomplish the Same Results



Sash Closed.



Sash Partly Open.



Sash Open Wide,

We recommend that sash be about 20 inches wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in two lengths, each 8 feet 3 inches long.

Material Furnished

- 16 Sash Links
- 4 Butt Hinges
- 12 Rubber Stops
 - 8 Fasteners with Bow Handles
 - 1 Pkg. Assorted
 - Screws
 - 6 Safety Locks
- 2 Sill Stops
- 6 Chafing Plates.
- 2 Pes. Upper Track
- 2 Pcs. Lower Track
- 2 Pcs. Threshold
- Set of Erection
- Details


List Price

8-Sash Set-Hardware complete for opening not over 16 feet 6 inches wide (between finished frames) by 5 feet high.

Weight, per set, 43 2/3 lbs.

Finish No. 1. Solid Brass, per opening.\$85.20 Finish No. 2. Brass Plated, per opening 70.80

Finish No. 3. Black, per opening..... 62.80











'A Hanger for any Door that Slides'

"AiR-Way" Multifold Window Hardware

For Opening Not Exceeding 16' 6" Wide by 5' High

10-Sash

5 Sash Folding Each Way Two 5-Sash Sets Will Accomplish the Same Results

We recommend that sash be about 20" wide. Set includes all hardware necessary for installation, including Brass Track and Brass Threshold. All parts except Track and Threshold are packed in one box. Tracks and Thresholds are sent in two lengths, each 8'3" long.

Material Furnished

20 Sash Links

8 Safety Locks

4 Butt Hinges 16 Rubber Stops 2 Sill Stops8 Chafing Plates

10 Fasteners with

2 Pcs. Upper Track

Bow Handles
1 Pkg. Assorted

2 Pcs. Lower

Screws

1 Set of Erection

Track
2 Pcs. Threshold

Details

List Price


10-Sash Set—Hardware complete for opening not over 16'6" wide (between finished frames) x 5' high.


Weight, per set, 48 lbs.


Finish No. 1. Solid Brass, per opening \$103.20 Finish No. 2. Brass Plated, per opening 86.20 Finish No. 3. Black, per opening 76.20

Sash Closed

Sash Half Closed, Half Partly Open







Sash Wide Open

Throw open the side of your house . . . and let the outdoors in!









20

Richards-Wilcox Mfg. Co. Aurora, Illinois



OPENINGS

Tear Out and Mail Direct to the R-W Mfg. Co., Aurora, Ill.

"AiR-Way" Specification Sheet

Please fill out this information blank so that we may be advised more fully regarding your requirements. If more than one opening is to be fitted please answer the first group of questions separately for each opening. We suggest also that you send a rough sketch of your plans with this sheet.

1 11 2	U	TIMITAGE)
How many openings do you wish to equip? ———	1st	2nd	3rd
	156	Ziid	- Ora
a. Total number of sash in each opening			
aa. Width of rough opening for frames			
TYPE 1.1 C.C. 1 1 in aids of fuerro			
- + 1 - 1 11 1			
b. Do you wish the sash all to open one way			
or part of them to open each way			1
d. If the sash are to fold both to right and left, how many will fold			
to the right?			
And how many to the left?			
e Height of each sash			
f. Width of each sash			
		7 7 , 1	1
(To Determine Width of Each Sash: From the width of rough	n openin	ig deduct al	lowances
riven below of the framework jambs and mullions. Next, divide t	his rema	aming spac	e by the
number of sash desired, answer will be the width of each individual sa	sh. In	dividual sa	sh $should$
number of sash desired, answer with be the width of each many			
not measure over 24 inches wide.)	:d+b of	and in 9/	" creator
Sash widths are taken on the inside face. The overall w	iath of	sasii is %16	greater
than width of inside face to allow for rabbetts.		WITT	IDT
		WHE	
ALLOWANCES		SASH	FOLD
		Part	All
		Each Way	
		Each way	One way
For standard design of "Air-Way" framework		$4\frac{1}{2}''$	$4\frac{1}{2}''$
For standard design of An-way framework		-/ 4	/ 4
$(2\frac{1}{4}$ " on each side)		$5\frac{7}{8}''$	3"
*For jambs and mullions		578	
(fixed and movable)	, 1		
Total allowances to be deducted from rough opening, leaving net spa-	ce to be	3	~1 ///
divided equally among the several sash		$10\frac{5}{8}''$	$7\frac{1}{2}''$
*If calculating widths of sash from finished opening deduct these amounts only.			
Please shock finish desired:			
No. 1			
No. 2			
No. 3			
		,	
See bottom of page 11 for description of finishes.			
Remarks:			
Your name			
Address			
Dealer's Name			
Dealer's Address			
A LOW AV		and the topology	TO PERSON









'A Hanger for any Door that Slides'







They Add to the Attractiveness of Your Home

Advantages of R-W Vanishing Doors

The advantages of vanishing doors over the common swing variety are so numerous and self-evident that we fear we may bore you with their enumeration. So we will be brief and mention only a few of the more important points.

We ask you to banish from your mind the impression gained in early childhood of the sliding doors that often required the united efforts of a strong family to make them operate.

That forerunner of the past half century of door hanger development is far removed from the present day silently vanishing door which disappears into the wall on adjustable ball-bearing hangers and wood-lined track. Today, a four-year-old child can easily open or close these doors.

The above illustration shows vanishing doors which operate upon R-W hangers and track. The utility and ornamental possibilities of having these doors vanish into the wall instead of swinging into the room are obvious. The doors interfere in no way with draperies, furniture, or fixtures of the home.

The advantages of vanishing doors over the comsired to finish adjacent rooms in different effects, the vanishing door obviates the embarrassment to harmony caused by opening a door of conflicting finish into an otherwise pleasing environment. For instance, the white door of a white trimmed dining room could not swing into a cypress trimmed room adjacent without embarrassment while a vanishing door between the two rooms could be finished on either side to suit the respective trims of the adjacent rooms and would never conflict with either one.


The wide opening between two rooms, which can be completely closed when desired, gives an effect of spaciousness which is most pleasing.


The use of vanishing doors is now becoming more general than ever before. Space is one of the most desired features in the bungalow, apartment or house and architects are taking advantage of the space saving features, which vanishing doors permit, and are specifying them in their plans. Confer with your architect on this point before you make a decision.

How Space Is Saved

The plan to the left shows three swinging doors; two of which open toward each other. These could be improved by the installation of vanishing doors, as illustrated to the right.

The occupants of thousands of apartments, particularly in our larger cities where space is at a premium, have found it necessary to substitute hanging drapes in places like this, where closet doors interfere with access to the closet.










R-W No. R-122 "Royal" Ball-Bearing Trolley House Door Hanger



22

Track: No. 16 gauge steel, hard maple lined; No. R-122 type, furnished with wood header; adjustable as illustrated. Length of track equals twice width of opening. Wheels: Grey Iron, lathe turned; 2½ inches diameter. Bearings, steel balls. Finish, blue lacquer. Packed complete with screws, overhead center stop, and floor guides. Weight, Full Set: Hangers, 10 lbs.; Half Set: Hangers, 5 lbs.; Track, per foot, 3 lbs.



Distance top of door to bottom of heading timber, 7¼ inches.
Minimum width of wall pocket, 2¼ inches.
Track can be easily removed without injury to plastered walls.

List Price of Hangers and Track

DOC	JBLE DOORS (Full Set	.)	SINGLE DOORS (Half Set)		
No.	Width of Opening	List	No.	Width of Opening	List
R122-24	4 feet	\$ 8,00	R122-121/2	2½ feet	\$4.00
R122-241/2	4½ feet	8.00	R122-13	3 feet	4.00
R122-25	5 feet	8.00	R122-131/2	3½ feet	4.40
R122-251/2	5½ feet	8.00	R122-14	4 feet	4.75
R122-26	6 feet	8.00	R122-141/2	4½ feet	5.15
R122-261/2	6½ feet	8.40	R122-15	5 feet	5.50
R122-27	7 feet	8.75	R122-151/2	5½ feet	5.90
R122-271/2	· 7½ feet	9.15	R122-16	6 feet	6.25
R122-28	8 feet	9.50	R122-16½	6½ feet	6,65
R122-29	9 feet	10.25	R122-17	7 feet	7.00
R122-210	10 feet	11.00	R122-171/2	7½ feet	7.40
			R122-18	8 feet	7.75

Note—When ordering track without hangers, the list price is found by deducting the list price of hangers without track from list prices given for various openings. Order by number.

R-W No. 11 Brass Bushed-Bearing House Door Hanger


Track: Hard maple and steel; No. 9 type; full sets for 7-foot double opening; half sets for 4-foot single opening. No. 9 track is provided with

cut-off slot one foot from each end, to allow for variation in size of opening. Wheels: Steel, $2\frac{1}{2}$ inches diameter with vulcanized fibre centers, noiseless. Bearings, brass bushed. Finish, blue lacquer. Packed complete with screws, overhead center stop, and floor guides. Weight, Full Set: Hangers, $8\frac{1}{4}$ lbs; track, $9\frac{1}{2}$ lbs. Half Set: Hangers, 4 lbs.; track, $5\frac{1}{2}$ lbs.

		-	
- 1	12f	Pr	100

No. 11—Full Set, including track (14 ft.)\$6	.00
No. 11—Half Set, including track (8 ft.)	.00
*No. 9—Extra Track. Per foot	.08
70.1	

*Note-No. 9 Track is made in 7 and 8-foot tengths only.




Clearance required above top of door, 7 inches. From top of door to top of track, 3¾ inches. Minimum width of wall pocket, 3 inches.





'A Hanger for any Door that Slides'


R-W No. 19 "Hero" Trolley Ball-Bearing House Door Hanger



ers, 5 lbs.; Half Set: Hangers, 21/2 lbs.; track, per foot, 21/4 lbs.

Distance top of door to bottom of heading timber, 6¼ inches, Minimum width of wall pocket, 2¼ inches, Track can be


width of wall pocket, 21/4 inches, Track can be easily removed without injury to plastered walls,



DOUBLE DOORS (Full Set)			SINGLE DOORS (Half Set)			
No.	Width of Opening	List	No.	Width of Opening	List	
19-24	4 feet	\$6.00	19-121/2	2½ feet	\$3.00	
19-241/2	4½ feet	6.00	19-13	3 feet	3.00	
19-25	5 feet	6.00	$19-13\frac{1}{2}$	3½ feet	3.25	
			19-14	4 feet	3.50	
$19-25\frac{1}{2}$	5½ feet	6.00	$19-14\frac{1}{2}$	4½ feet	3.75	
19-26	6 feet	6.00	19-15	5 feet	4.00	
$19-26\frac{1}{2}$	6½ feet	6.25	$19-15\frac{1}{2}$	5½ feet	4.50	
19-27	7 feet	6.50	19-16	6 feet	4.75	
$19-27\frac{1}{2}$	7½ feet	6.75	$19-16\frac{1}{2}$	6½ feet	5.00	
19-28	8 feet	7.00	19-17	7 feet	5.25	
19-29	9 feet	7.50	$19-17\frac{1}{2}$	7½ feet	5.50	
19-210	10 feet	8.00	19-18	8 feet	5.75	

No. 19—Hangers for double doors, without track. \$3.00 No. 19—Hangers for single doors, without track. 1.50

Note—When ordering track without hangers, the list price is found by deducting the list price of hangers without track from list prices given for various openings. Order by number.



Clearance required above top of door, 7½ inches, From top of door to top of track, 3% inches, Minimum width of wall pocket, 3 inches.

R-W No. 12 "Model" Roller-Bearing House Door Hanger

Track: 1½x3-inch steel; No. 63 type; full sets for 7-foot double opening; half sets for 4-foot single opening. Wheels: Steel, 3% inches diameter with vulcanized fibre centers. Bearings, steel rollers. Finish,

blue lacquer. Packed complete with screws, overhead center stop, and floor guides. Weights, Full Set: Hangers, 91/4 lbs.; track, 14 lbs. Half Set: Hangers, 41/4 lbs.; track, 8 lbs.

List Price

No. 12—Full Set, including track (14 ft.)	\$6.00
No. 12—Half Set, including track (8 ft.)	3.00
*No. 63—Extra Track. Per foot	08

*Note—No. 63 Track is made in 4, 6, 7, 8 and 10 ft. lengths.

Discount...





Double Adjustment an Important Part of R-W Vanishing House Doors






Fig. B. Close View Showing Slotted Plate and Adjusting Screw.

To remove track loosen front and center adjusting screws and draw track for ward from slot in rearend of header as indicated by arrows.

Pocket

*

Fig. A. Elevation of Doorway Structure Showing Track Installed, and (Dotted Lines) Unfastened From Header. Slotted Plate and End Adjusting Screw Suspend Track at Back End, (See Upper Left Hand Corner).

Frequently houses settle after vanishing doors are installed. As a result the doors stick at the bottom and the track becomes out of alignment with the threshold.

That's the point where the accessible adjustment provided in R-W door hangers of the header type is appreciated.

Usually the proper adjustment of the door can be made by turning with a screw driver the accessible adjusting screw of the hanger at one or both edges of the sliding door (Fig. C).

Further adjustment may be secured by raising or lowering the track. This can be easily done by inserting a screw driver in the opening between the soffits through which the hanger pendant travels, and turning the accessible adjusting screws which suspend the track directly over the doorway opening (Fig. C).

Very rarely it is found necessary to raise or lower the end of the track located in the wall pocket. If it is necessary, the R-W House Door Hanger arrangement makes provision for the adjustment.

By moving the detachable parts of the soffits and jambs and unscrewing the hanger adjusting screws so that the hanger comes apart, the door may be lifted out and the track removed without difficulty. To remove the track it is only necessary to unscrew from the header the adjusting screws in the track over the opening (Fig. C), pull the track forward to disengage it from the slotted plate at the back end (Figs. A and B), and then withdraw it entirely from the pocket.

The adjusting screw at the back of the track (Fig. B) may then be regulated as required; the track again inserted into the pocket; the head of the adjusting screw at the back end of the track slipped into its slot in the header plate; the two screws over the opening screwed into the header—and the track adjustment is complete.





Fig. C. Cross Section of R-W Door Hanger Installation Showing Relative Positions of Hanger, Track, Accessible Hanger Adjusting Serew, Accessible Track Adjusting Serew, Header, Door, Soft and Casing.





A Hanger for any Door that Slides"

The Most Important Part of Your Garage



WE believe the most important part of a garage is the doorway, and the method employed in opening and closing the doors. Of course, we make garage door hardware, so we may be prejudiced. But at that a more important part is hard to imagine, isn't it?

In any event the doors are subjected to very rough usage. They are exposed to the extremes of climatic conditions, blistering sun, bitter zero, soaking rains, warping heat . . . and high wind pressure. Some people treat doors harshly, often jerking, slamming, and sometimes accidentally backing their autos into them.

It is important that the doors be strongly constructed in the first place. But that is not half of it. They must fit snugly and tightly when closed, to keep out the wind, rain and cold. They must operate smoothly, easily and quickly, with a minimum of adjustment, attention or expense, from year to year. They must slide and fold inside the garage, flat against the wall, leaving a wide, clear opening.

We believe "Slidetite" garage doors to be the most perfect, from every standpoint, of any style upon the market today. We ought to know, because we have manufactured garage door hardware for years. We sell hardware for manipulating doors in almost every conceivable way. We know what our competitors make. Is it not fair to presume that if there was a better garage door equipment than "Slidetite" that we would make it? There are, of course, a

Scidetites Patented

Garage Door Hardware
For Private and Public Garage Doors

few situations in which "Slidetite" can not be used to advantage. When that is the case we frankly tell you so, and advise you as to the best equipment suited for each case. In the majority of cases, however, "Slidetite" is the ideal installation for garage doors.







Slidetites Garage Door Hardware

For Private and Public Garage Doors







Interior view, showing application of No. 517 Bolt as used with three-door set



view of four-door garage under sun p under sun parlor



Elevation showing proper location of "Slide-tite" three-door hardware, including R-W tite" three-door No. 514 Bolts.



Floor plans of three-door 'Slidetite' doorway, showing doors closed, doors partially opened, doors open parallel with sidewalls, doors open parallel with front wall, giving abso-late clearance from jamb to jamb.

ARAGE doors equipped with this fixture fold and slide inside I the building, requiring only minimum space. Recommended for doors not over three feet wide.

The 3-door "Slidetite" set of hardware makes an ideal equipment for the ordinary garage door-way, two of the doors folding to one side of the opening, the third door being hinged to the jamb or to the middle door. When desired, however, any number of doors from 4 to 10 in one opening can be used. A ten-door outfit will take care of an opening up to 30 feet wide.

Prices of complete sets do not include the lock for entrance door.

List Price—3 Door Sets

"Slidetite" R-W No. 435 Complete Sets

3-Door Sets for openings not to exceed 9 feet wide and for doors weighing up to 125 pounds each.

With No. 514 Top and Bottom Spring Bolts. Weight per set, 40 lbs. Price, complete.....\$14.00

With No. 514 Top Spring Bolts and No. 524 Cane Bolts.

Weight per set, 49 lbs. Price, complete...... 14.00


With No. 517 Top and Bottom Cremone Bolt. Weight per set,

56 lbs. Price, complete...... 17.60

A 3-Door Set Consists of the Following Hardware

- 1 No. 425-1 Hanger
- No. 435x31-C Center Bracket No. 435x31-E End Bracket
- 1 No. 435x31-I Intermediate Bracket
- 1½ pair No. 435 Butt Hinges, Japanned
- 1½ pair No. 311 Half Surface Butt Hinges, Japanned 1½ pair No. 435 Surface Hinges, Japanned
- 7 feet No. 31 Track (1-7 feet)
- 2 No. 81-1 Bow Handles (1 is furnished when No. 517 Cremone Bolt is used)
- No. 271 Center Floor Guide
- No. 435-72 Bumper Shoes
- No. 514 Top and Bottom Spring Bolts, or
- No. 514 Spring Bolt and 1 No. 524 Cane Bolt, or
- No. 517 Top and Bottom Cremone







''A Hanger for any Door that Slides''

Slidetites

The Last Word In Garage Door Hardware



The above catalog, showing our entire line of Garage Door Hardware, will be sent you on request.



"Slidetite" two-track, four-door hardware on double doorway showing doors in closed position, partially opened position, and wide open position. Illustration shows doors equipped with No, 517 Top and Bottom Cremone Bolt,

TE furnish all necessary hardware. Direction sheet, showing the details, furnished with each order. Packed, complete sets, in wood box, less track.

Intermediate and end brackets are adjustable. Brackets are adjustable to permit track to be set at angle suitable to thickness and position of doors. Hangers support and guide the end of the door and prevent sagging. Steel wheels, roller bearings. Vertical adjustment. Ball-bearing swivel pendants.

List Frice—4 Door Sets

"Slidetite" R-W No. 435 Complete Sets

2-Track 4-Door Sets for openings not to exceed 12 feet wide, and for doors weighing up to 125 pounds each.

With No. 514 Top and Bottom Spring Bolts. Weight per set, 83 pounds. Price, complete.....\$21.00

With No. 514 Top Spring Bolts and No. 524 Cane Bolts. Weight per set, 84 pounds. Price, complete...... 21.00


With No. 517 Top and Bottom Cremone Bolts. Weight per set, 97 pounds. Price complete...... 27.20

Discount


A 2-Track 4-Door Set Consists of the Following Hardware

- No. 435-1 Hangers
- No. 435x31-C Center Brackets No. 435x31-E End Brackets No. 435x31-I Intermediate
- Brackets 3 pair No. 311 Half Surface Butt
- Hinges, Japanned 3 pair No. 311 Half Surface Butt
- Japanned 14 feet No. 31 Trolley Track
- 4 No. 81-1 Bow Handles (2 are furnished when No. 517 Cremone Bolt is used)
- No. 271 Center Floor Guide
- No. 435-72 Bumper Shoes
- 4 No. 514 Top and Bottom Spring Bolts, or
- 2 No. 514 Spring Bolts and 2 No. 524 Cane Bolts, or
- 2 No. 517 Bolts.

NOTE: "Slidetite" is made for openings having from 3 to 10 doors.



Elevation showing proper location of "Slidetite" two-track four-door hardware, including numbers 514 and 524 Bolts.




Floor plans of two-track four-door "Slidetite" doorway, showing (1) doors closed, (2) doors partially opened, (3) doors open parallel with sidewalls, (4) doors open parallel with sidewalls, (4) doors open parallel with front wall, giving absolute clearance from jamb to jamb.














Hanger No. 435-1




Full Size Cross-Section of No. 435x31 Trolley Track



Cane Bolt No. 524-1



Half Surface Butt Hinge No. 311







Center Floor Guide No. 271, and Bumper Shoes No. 435-72.







End Bracket No. 435-E

Detail of Hardware and List Price of Parts

	With No. 31 Track—For Doors Weighing up to 125 Lbs. Each		
DESCRIPTION	Number	Price	Shipping Wt., Lbs.
Hangers, Roller Bearing, each	435-1	£3.50	31/2
*Trolley Track, per foot	435x31	.33	1.6
Center Track Brackets, each	435x31-C	. 30	1
Intermediate Track Brackets, each	435x31-I	. 70	312
End Track Brackets, each	435x31-E	1.00	5
Surface Hinges, japanned, per pair	435-2½"x4"	. 80	9
Butt Hinge, japanned, per pair	435-4"x4"	, 60	11/2
Half Surface Butt Hinges, japanned, p r pair	311-4"	1.60	33/4
Center Floor Guide, each	271	.96	21/2
Bumper Shoes, each	435-72	. 12	5 oz.
Cane Bolt, each	524-1	.90	3
Spring Bolt, Top or Bottom, each	514-1	.80	21/4
Cremone Bolt, Top and Bottom, each	1 517	5.60	191/2
The state of the s	00 and 07		


Note—Prices for Complete Sets of Hardware shown on pages 26 and 27.

*Length of each track equals width of two doors plus approximately one foot.

Three door and one-track four-door openings require one track. Two-track four-door, five-door and six-door openings require two tracks.



Spring Bolt
Top and Bottom
No. 514-1
Illustration
Shows Bolt on
Bottom of Door



R)V-517

No. 517 Top and Bottom Cremone Bolt



'A Hanger for any Door that Slides''

R-W No. 235 Where Front Wall Space Is Limited Use— MOSYNE Right Angle Garage Door Hardware

Patented

In a garage where front wall space is limited and where it is desired to secure maximum use of the floor space, "Slyda-Syde" R-W No. 235 Garage-Door Equipment makes an unusually satisfactory installation.

Even very heavy doors operate lightly on "SlydaSyde"

hardware.


"SlydaSyde" doors when open stand along the side wall at right angles to the opening, inside the building and require a negligible amount of space for their operation in swinging around the corner.

The hardware is adaptable to various doorway conditions and arrangements, including—Single Doors with space between the jamb and the side wall; Double Doors with space between the jamb and side walls; Single and Double Doors with jamb adjacent to the side wall; Pair of Doors Hinged Together for opening with space between the jamb and side wall; Three Doors Hinged Together.

The plans below illustrate only three of the nine situations where "SlydaSyde" hardware can be used to advantage.




Fig. A-556. Illustration of interior of garage doorway equipped with single door "SlydaSyde" Hardware CC.



Three Doors Hinged Together, one folding and all sliding to one side.







"CornR-Wise" Is Another Popular Style

For Use Where Front Wall Space Is Limited






Fig. A-582—Interior view, doorway equipped with "CornR-Wise" hardware for double doors


R-W No. 635

The particular feature which distinguishes the operation of this style door from that on the preceding page is the exceptionally narrow space between the jamb and the side-wall in which this hardware can be installed. Where "SlydaSyde" doors on curved tracks require in most instances a clearance of 21 inches in the corners, "CornR-Wise" requires only 6 inches. Their operation in other respects is very similar.

It is impossible to show upon one page plans of all the various "CornR-Wise" doorway arrangements.


"CornR-Wise" is adaptable for openings where: Single Doors slide to one side; Double Doors, one of which slides to each side; Two Doors Hinged Together and sliding to one side, and Two Pairs of Doors Hinged Together, one pair of which slide to each side. The two sets of plans illustrated below show only two of the above combinations.

Further information together with prices will be gladly furnished upon request.



Single Door Sliding to One Side

For openings up to 10 feet wide. For doors weighing up to 300 pounds each.








"A Hanger for any Door that Slides"



31

R-W No. 534 Garage Swing Door Hardware

With 10-Inch Heavy Mortise Pintel Hinges



Exterior View. Note the heavy 10-in. Anti-Friction Hinges Furnished with this Set



Exterior View. Note how the No. 99 Door Dogs hold the Doors Open

All the hardware in this set is R-W Standard goods and built to give satisfactory service.

The Hinges should not be confused with the common T Hinges furnished with other sets, as these are high grade 10" Mortise Pintel, Steel Anti-friction Hinges.

The No. 514 Spring Top Bolt and No. 524 Bottom Cane Bolt will hold the door firmly when closed, and the latch furnished affords a handle as well as a plate for attaching padlock.

One No. 99 Door Dog is furnished for each door. These Dogs will positively hold the doors open at any desired position and prevent the wind from banging them around. Prevents accidents to fenders and head lights.


This set of hardware comes packed complete with all bolts and screws necessary for attaching, in strong box, and consists of the following:

- 1 No. 514-1 Spring Top Bolt
- 1 No. 524-1 Bottom Cane Bolt
- 1 No. 71-1 Bow Handle
- 1 No. 534 Latch
- 1 Pair No. 99 Door Dogs
- 3 Pairs No. 1036-10" Hinges
- 1 Package Screws and Bolts

NOTE—If ordinary extra heavy reserved pad Tee Hinges are desired instead of the No. 1036 type, order set No. 334.

No Lock is included in this set of Hardware






Parts for R-W No. 534







With 18-Inch Heavy Mortise Pintel Hinges and Heavy Grip Handle Latch



Exterior View. Note the heavy 18-in, Anti-Friction Hinges Furnished with this set



Exterior View. Note how the No. 99 Door Dogs hold the Doors Open

Each item in this set of hardware for swing doors is quality hardware.

These hinges are heavy enough for large doors and are of the mortise pintel, anti-friction type.

The No. 350 Latch has two Extra Heavy Grip Handles, and Latch Thumb Lifts. A heavy Bow Handle is furnished for the other door; also No. 514 Top Spring Bolt and No. 524 Bottom Cane Bolt.


Two Lock Plates are furnished. One No. 99 Door Dog is included for each door which will positively hold the doors open at any desired position. These prevent the wind from banging the doors around. They prevent accidents to fenders and head lights.

This set of hardware comes packed complete with all bolts and screws necessary for erection and consists of the following:

- 1 No. 514-1 Top Spring Bolt
- 1 No. 524-1 Bottom Cane Bolt
- 1 No. 81-1 Bow Handle
- 1 No. 350 Latch
- 1 Pair No. 99 Door Dogs
- 2 No. 436 Lock Plates
- 2 Pair No. 1036-18" Hinges
- 1 Pair No. 1036-10" Hinges
- 1 Package Screws and Bolts

No Lock is included in this set of Hardware





Parts for R-W No. 634







'A Hanger for any Door that Slides'

R-W No. 643 Door Closers and Checks







Standard Attachment



Attachment by Flush Bracket



Attachment by Corner Bracket



Attachment by Soflit Bracket

Approved by the National Board of Fire Underwriters

General Construction:

The R-W Door Closer and Check employs the old, time tried crank and pitman checking mechanism, improved and simplified. In R-W Checks all working parts used in the checking cylinder are made of steel drop forgings.

The Spring:

Broken Springs.—It is impossible to over-wind the spring in the R-W Check. While the tension of the spring can be adjusted to suit conditions by the pawl and tooth-dog, the limited number of teeth on the tooth-dog makes over-winding impossible. The spring power is a unit in itself, which can be removed if desired without taking check off the door.

Checking Mechanism:

The checking mechanism is entirely separate from the operating mechanism. The spindle stuffing box is above the liquid level. The liquid is a non-freezing oil in which the main working parts are emersed, has high lubricating qualities and contains no alcohol.

Reversible Feature:

The R-W Check can be changed from right to left by simply swinging the arm from one side to the other, the pawl that engages the toothed dog being so placed as to engage on either side. These features make the Richards-Wilcox the only truly reversible check on the market.

General Features:

No special wrenches or tools are required in assembling or winding up the spring.

Table of Sizes and Prices

Size	Description of Doors	Weight, Each	List Price Each	
643-1	For screen and very light interior doors	6 lbs.	\$3.25	
643-2	For light interior doors not exceeding 3 feet wide and vestibule doors not ex-	-1 ()		
643-3	ceeding 2 ft. 6 in. wide	$7\frac{1}{2}$ lbs.	4.25	
	exceeding 3 ft. wide, or light outside doors not exceeding 2 ft. 6 in. wide	10 lbs.	5.00	
643-4	For heavy interior doors or medium weight outside doors not exceeding			
	3 ft. wide	12 lbs.	6.00	
643-5	For heavy outside doors not exceeding 3 ft. 6 in. wide	15 lbs.	8.00	
643-6	For extra heavy outside doors and large doors operated against very strong			
	drafts.	171/6 lbs.	10.00	

The above calculations are based on Standard doors. Extra heavy doors or doors subject to strong drafts require a check one size larger than specified. Checks are furnished regularly in gold bronze. Checks furnished in silver bronze or ivory black at the same prices as gold bronze. Prices for special finishes on application.

Brackets

Prices of Different Styles of Brackets in Gold Bronze, Ivory Black or

Style	Size	Size	Size	Size	Size	Size
of Bracket	No. 1	No. 2	No. 3	No. 4	No. 5	No. 6
Soffit Bracket	.70	\$.60	\$.70	\$.80	\$1.00	\$1.20
Flush Bracket		.80	1.00	1.20	1.40	1.50
Corner Bracket		1.00	1.20	1.50	1.80	1.90



